Play & Drive

Soft Sports Kit

USER'S GUIDE

for Wii™

dreamGEAR

www.dreamgear.net

Package Contents:

- Wii Remote Cradle
- Tennis Racket Extension
- Baseball Bat Extension
- Golf Club Extension
- Micro Racing Wheel

SET-UP:

1. Place your Wii Remote into the Sports Kit's Remote Cradle.

2. Depending on which game is being played, chose the appropriate remote extension.

3. With Wii remote inserted into Remote Cradle, attach the Tennis Racket, Golf Club, or Baseball Bat by sliding the extension onto the Remote Cradle.

MICRO RACING WHEEL:

1) Place the Wii remote into the Micro Racing Wheel with the directional pad facing the left side.

2) The Micro Racing Wheel features an infrared pass-thru, this feature allows the user to make on screen selections without having to remove the Wii remote from the wheel.

Note: Micro Racing Wheel not made of soft foam.



WARNING!

Your Wii™ Remote with the Sports Kit extensions attached can be harmful. Never swing your Wii Remote with other people near you.

dreamGEAR

www.dreamgear.net

FOR TECHNICAL SUPPORT
PLEASE CONTACT: 1-877-999-DREAM
or support@dreamgear.net